


Software Driver for FTDI Cable (item 3661U) Installation Instructions

1. Log into the Spectrum website, www.specmeters.com.
2. Click the **Support** tab.
3. Click the **Software** option from the Technical Support options on the left side of the screen.
4. Scroll to the bottom of the screen and click the **USB Software and Driver Updates** option.
5. The first option on this page is for the FTDI cable. Click the link (circled below) to connect to the driver file web page.



6. Click the **setup executable** file for the Windows driver (circled below). The file will download to your computer. The downloaded file will be named **CDM21224_Setup.zip**.

Currently Supported VCP Drivers:

| Operating System | Release Date | Processor Architecture | | | | | | | Comments |
|------------------|--------------|------------------------|--------------|-----|-----|--------|--------|-----|--|
| | | x86 (32-bit) | x64 (64-bit) | PPC | ARM | MIPSII | MIPSIV | SH4 | |
| Windows* | 2016-10-10 | 2.12.24 | 2.12.24 | - | - | - | - | - | WHQL Certified. Includes VCP and D2XX. Available as a setup executable . Please read the Release Notes and Installation Guides . |

7. Unzip and run the executable file to install the driver.

8. A communication (COM) port will be created when the cable is plugged into your computer. Go to the **File** menu, select the **Preferences** option, and click on the **Communication** tab. Specware software will automatically identify the port for this cable as **USB Serial Port**. Select this option and click the **OK** button.

