



# Micro Station Waterproof Enclosure

## PRODUCT MANUAL

Item # 3659WD1



***Spectrum***  
***Technologies, Inc.***

# COMPONENTS



Thank you for purchasing a WatchDog Micro Station Waterproof Enclosure. The enclosure comes with four sensor cable glands, four gland caps and four gland plugs.

---

For customer support, or to place an order, call Spectrum Technologies at (800)248-8873 or (815)436-4440 between 7:30 a.m. and 5:30 p.m. CST, FAX at (815)436-4460, or E-mail at [info@specmeters.com](mailto:info@specmeters.com).

Spectrum Technologies, Inc  
12360 S Industrial Dr. East  
Plainfield, IL 60585  
[www.specmeters.com](http://www.specmeters.com)

---

1. Remove gland plugs and caps for the number of sensor cables being used. Unused glands should remain plugged.



2. Run the sensor cables through the gland caps and then through the gland.



3. Plug stereo pin end of sensor cables into the WatchDog Micro Station sensor ports.



4. Close the Enclosure lid. Remove slack from sensor cables by gently guiding cables through the glands. Kinking of cables in the enclosure could damage the wires.



5. Screw the gland caps onto each gland. Using pliers may be necessary.





**IMPORTANT!** The enclosure can only be waterproof if all the connections are snug. If you can easily slide a cable in or out, water will be able to enter the enclosure. Tighten the gland cap. Make sure that any unused glands are secured with gland plugs.

## **WARRANTY**

---

This product is warranted to be free from defects in material or workmanship for one year from the date of purchase. During the warranty period Spectrum will, at its option, either repair or replace products that prove to be defective. This warranty does not cover damage due to improper installation or use, lightning, negligence, accident, or unauthorized modifications, or to incidental or consequential damages beyond the Spectrum product. Before returning a failed unit, you must obtain a Returned Materials Authorization (RMA) from Spectrum. Spectrum is not responsible for any package that is returned without a valid RMA number or for the loss of the package by any shipping company.

# ***Spectrum<sup>®</sup>*** ***Technologies, Inc.***

**3600 Thayer Court  
Aurora, IL 60504  
(800) 248-8873 or (815) 436-4440  
Fax (815) 436-4460  
E-Mail: [info@specmeters.com](mailto:info@specmeters.com)  
[www.specmeters.com](http://www.specmeters.com)**