

# Powered Direct Connect 75 FT Cable Kit

## PRODUCT MANUAL

Items 3660DP & 3927C75

***Spectrum***<sup>®</sup>  
***Technologies, Inc.***

3600 Thayer Court  
Aurora, IL 60504  
(800) 248-8873 or (815) 436-4440  
Fax (815) 436-4460  
E-Mail: [info@specmeters.com](mailto:info@specmeters.com)  
[www.specmeters.com](http://www.specmeters.com)

# POWERED DIRECT CONNECT 75 FT CABLE

3660DP (for Weather Station) and 3927C75 (for Retriever)

Follow these steps to connect the powered 75-ft cable to your Weather Station or Retriever.


## KIT CONTENTS

- A. AC/DC power supply  
3660DP: 6V, 1.25A  
3927C75: 12V, 0.7A
- B. Direct Connect Power and Data Adapter
- C. 75-ft 6-conductor extension cable



## INSTRUCTIONS

**1** Connect 75 ft cable end without the gland (cord grip) to the adapter.




**2** Connect 9-pin female end of the adapter to your PC, either directly to a serial port or using a USB-to-Serial adapter (3661U9).

**3** Connect the power supply to the A/C adapter.

(Retriever is shown here for illustration.)

**4** Remove the existing gland from the rightmost position of the Weather Station or Retriever.



### **3660DP NOTICE:**

Remove all alkaline batteries from the Weather Station before plugging the cable into the station.

**5** Insert the cable into the Station or Retriever through the open gland hole and plug it into the AUX port. Screw the gland (cord grip) into the hole to secure the cable and seal the opening.

