

# WatchDog Mid-Range Wireless Base Station

## Installation Instructions

Catalog Number 3391B



### Package Contents


Transceiver with 50 ft. 4-wire cable  
9-pin female RS-232 connector with attached DC power jack.  
A/C adapter.  
2 U-bolt mounting brackets.



### Installation

Connect the DC power jack at the end of the Base Station Transceiver cable to the A/C adapter. The 9-pin serial connector plugs directly into your computer's serial port (a USB to serial converter cable is required for PCs without serial ports). The Base Station Transceiver should be placed at as great a height as possible to facilitate line of sight with the weather station. If necessary, the length of the cable can be increased with an extension cable. Be careful not to cross the wires.

It may be necessary to experiment with placement of the two transceivers to attain the best line of sight. The signal can pass through wood, vegetation and concrete but metal will block the signal. Ideally, the base station transceiver should be attached outside the building for maximum performance.



Please assemble and test your wireless system (the base station plus the remote weather station) indoors first. Simple problems, such as inserting batteries backwards, are far easier to correct when they don't involve a journey.

*Spectrum*  
*Technologies, Inc.*

Spectrum Technologies, Inc.  
12360 S Industrial Dr East  
Plainfield, IL 60544  
(800) 248-8873 or (815) 436-4440  
FAX: (815) 436-4460  
E-Mail: [info@specmeters.com](mailto:info@specmeters.com)  
[www.specmeters.com](http://www.specmeters.com)